



# INSTALLATION

## CHROME OUTER WINDSHIELD TRIM

## 2630

### PARTS INCLUDED

- 1 Chrome Outer Cross Trim
- 1 Right Side Outer Trim
- 1 Left Side Outer Trim
- 1 Hardware kit Containing:
  - 9 1/4"-20 Acorn Nuts
  - 7 1/4"-20 X 5/8" Flat Socket Cap Screws
  - 2 1/4"-20 X 7/8" Flat Socket Cap Screws
  - 1 Zombie Emblem
  - 1 Grooved Emblem
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

### THANK YOU FOR CHOOSING KÜRYAKYN!

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND NOTICES REGARDING THE USE AND CARE OF THIS PRODUCT.**

#### NOTICE

This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

#### NOTICE

**IF INSTALLING THIS PRODUCT FOR ANOTHER PARTY, PLEASE MAKE SURE THEY RECEIVE THIS COPY OF THE INSTALLATION INSTRUCTIONS SO THEY ARE AWARE OF THE IMPORTANT INFORMATION CONTAINED IN THEM.**

### TOOLS SUGGESTED

Set of Torx Wrenches, Set of Hex Wrenches, Set of Combination Wrenches

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

#### STEP 1

Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

#### NOTICE

**Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.**

#### STEP 2

Remove the windshield from the motorcycle and place it on a soft cloth or blanket.

#### STEP 3

Remove the nine fasteners holding the existing brackets in place on the windshield. Set this hardware aside, it will not be reused. PIC 1

### CUSTOMER SERVICE

877.370.3604 (toll free)

### INSTALLATION QUESTIONS

techsupport@kuryakyn.com  
or call 715.247.2983

### LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Küryakyn and a customer.
- Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Küryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.
- Küryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

### ABOUT OUR CATALOG

For purchasing Küryakyn® products, you can receive a complete catalog free of charge.

Send the Proof-of-Purchase below with your address to: Küryakyn, P.O. Box 339, Somerset, WI 54025.

Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved.



**STEP 4** Determine the left and right (sitting on the bike) side Outer Trim. PIC 2

**STEP 5** From the front side of the windshield: Insert one of the included 1/4"-20 X 5/8" flat socket cap screws through the center hole in the outer Chrome Cross Trim, through the windshield, through the OEM rear cross trim (labeled 1 in PIC 3 and 4) and secure with one of the included 1/4" Acorn Nuts. Leave finger tight for now. Repeat for the two outside locations (labeled 3 and 5 in PIC 3 and 4) in the Cross Trim.

**STEP 6** From the front left side of the windshield: carefully slide the left Outer Trim through the notch (PIC 4) on the left side of the Chrome Cross Trim. Insert one of the included 1/4"-20 X 7/8" flat socket cap screws through the top location (labeled 2 in PIC 3 and 4) in the outer Chrome Cross Trim, through the Outer Trim, windshield, OEM rear cross trim and mounting bracket. Secure with one of the included 1/4" Acorn Nuts. Leave finger tight for now. Repeat for the right Outer Trim using location 4 in PIC 3 and 4.

**STEP 7** Starting at the bottom of the left front side of the windshield: insert one of the included 1/4"-20 X 5/8" flat socket cap screws through the Outer Trim, through the windshield, through the OEM mounting bracket (labeled 9 in PIC 3 and 4) and secure with one of the included 1/4" Acorn Nuts to the threads. Leave finger tight for now. Repeat for location 8 in PIC 3 and 4.

**STEP 8** Starting at the bottom of the right front side of the windshield: insert one of the included 1/4"-20 X 5/8" flat socket cap screws through the Outer Trim, through the windshield, through the OEM mounting bracket (labeled 7 in PIC 3 and 4) and secure with one of the included 1/4" Acorn Nuts to the threads. Leave finger tight for now. Repeat for location 6 in PIC 3 and 4.

**STEP 9** Tighten the Acorn nuts in the order shown in PIC 3. **DO NOT OVER-TIGHTEN** as this may cause the windshield to crack.

## NOTICE

**It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not provide warranty coverage on products or components lost due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.**

**STEP 10** Attach your choice of Emblem to the center of the outer Chrome Cross Trim by pressing it into the dual lock patch on the Cross Tim. PIC 4

