

Copyright © 2019 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 52-951

DASH SCREEN PROTECTOR

FITMENT: HONDA GOLDWING/GOLDWING TOUR 2018-NEWER

5/29/2019

TOOLS NEEDED: CLEAN LINT FREE CLOTH

PLASTIC SQUEEGEE

RUBBING ALCOHOL

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

ESTIMATED INSTALLATION TIME: 15 TO 20 MIN.

THIS PRODUCT HAS TO BE INSTALLED INDOORS IN TEMPERATURE BETWEEN 50°F AND 80°F WITH RELATIVE HUMIDITY BETWEEN 30% AND 60%.

## NOTICE

THIS IS AN ADHESIVE BACKED PRODUCT. CAUTION MUST BE TAKEN DURING INSTALLATION TO PROPERLY POSITION FOR ONE TIME PLACEMENT. REPEAT TRIALS WILL RESULT IN FAILURE OF THE ADHESIVE.

### INSTALLATION:

1. TEST FIT SCREEN PROTECTOR TO BETTER UNDERSTAND LOCATION AND FITMENT ON THE DASH (FIG. 1).
2. USING RUBBING ALCOHOL AND A LINT FREE TOWEL CAREFULLY CLEAN THE SURFACE OF THE INSTRUMENT PANEL. IF YOU HAVE USED ANY POLISH (i.e. Rain-X, Plexus, Novus) OR OTHER PRODUCTS ON THE PANEL YOU WILL NEED TO CLEAN IT MORE THAN ONE TIME TO REMOVE EVERYTHING. **BE CAREFUL NOT TO SCRATCH THE SCREEN WHEN CLEANING.**
3. USE THE SUPPLIED CLEANING WIPE TO REMOVE ANY DUST LEFT ON THE PANEL. (FIG. 2).
4. LET DASH DRY COMPLETELY.
5. VERIFY THE BACKING SIDE AND PROTECTOR SIDE OF THE SCREEN PROTECTOR (FIG. 3). WHEN YOU START TO PEEL THE LAYERS APART, THE BACKING IS THE THIN LAYER AND THE PROTECTOR IS THE THICKER LAYER. ALSO THE THIN BACKING IS SMOOTH ON BOTH SIDES, THE PROTECTOR HAS A LIGHT ADHESIVE ON THE BACK SIDE. **(TO AVOID DIRT OR FINGER PRINTS IN THE SCREEN, DO NOT TOUCH BACK OF THE SCREEN PROTECTOR WHERE THE BACKING IS REMOVED).**
6. ON EITHER END OF THE SCREEN PROTECTOR, CAREFULLY PEEL PART OF THE BACKING FROM THE SCREEN PROTECTOR (FIG. 3). **DO NOT REMOVE COMPLETELY.** CAREFULLY LINE UP THE SCREEN PROTECTOR ON THE DASH AND PRESS THE END DOWN TO ADHERE IT TO THE DASH (FIG. 3).
7. CAREFULLY CONTINUE TO PEEL THE BACKING WHILE PRESSING THE SCREEN PROTECTOR ONTO THE DASH ALONG THE CENTER (FIG. 3) (START IN THE MIDDLE AND WORK UPWARDS AND DOWNWARDS USING A PLASTIC SQUEEGEE TO WORK ANY AIR BUBBLES OUT UNTIL THE ENTIRE SCREEN PROTECTOR IS SECURELY IN PLACE). **RECOMMENDED TO USE A PLASTIC SQUEEGEE (SIMILAR TO FIG 4) FOUND AT ANY LOCAL AUTO PARTS STORE.**
8. CLEAN SCREEN/PROTECTOR WITH A LINT FREE CLOTH.
9. LET ADHESIVE CURE FOR 24 HOURS BEFORE USING BIKE.

